

Service Entrance Rated Type 1 - UL 1449 5th Edition

Installation Instructions

1. Preparation for Installation of Surge Protection Device (SPD)

A. Verify that the system voltage and wiring configuration are the same as the enclosed SPD by metering the panel voltage and checking it against the product label located on the SPD.



B. Review the installation area to ensure that proper space is available to properly mount and install the SPD. The enclosure should be mounted no more than 3 feet away from the distribution panel.

C. Check that the building's facility grounding system meets all NEC

& CEC requirements as well as local codes. A low resistance ground system is essential to the proper functioning of any SPD. The soil resistance level should be no more than 25 ohms. This can be verified by performing a soil resistivity test.

Technical Assistance Call: 703-687-4057 Register Online at:

https://surgewarrantyonline.com




Figure 2




Figure 3

Surge Protector for Delta Systems 3 Phase Delta, 3W+G 240 480 600 G

You must verify 240v leg in your application and connect 240v marked wire on SPD to same point.

* IF 120 LEG ON SPD IS BLOWN ON INSTALL, THERE IS NO WARRANTY.



Important: Risk of electrical shock. This device should only be installed by qualified personnel.

2. Location of Surge Protection Device (SPD)

A. For service entrance applications, install the SPD at the main distribution panel on the load side after the main disconnect.

B. For feeder/sub-panel applications, install the SPD directly adjacent to the panelboard.

IMPORTANT! Remember to keep conductor lead length to a maximum of 3ft or less.

3. Wiring of Surge Protection Device (SPD)

A. TURN OFF the power to the distribution panel where the SPD will be installed.

Optional: Install a circuit breaker to feed the SPD. This will allow safety personnel to remove power from the device in order to diagnose or service the unit. In addition, the device incorporates internal fusing, UL & CSA approved, that will protect against short circuit fault conditions within the unit.

B. Nipple mount SPD or install either a rigid or flexible metal conduit between the SPD and the distribution panel.

C. Run wires of SPD to distribution panelboard - See wiring diagrams for details.

D. Tighten and recheck all connections.

NOTES: Check wiring before applying power.

Vortex[™] Series R, Three-Phase Commercial Series Warranty

PSP Product Warranty 25 Year Limited Commercial Warranty Coverage for the Vortexx Series R, Three-Phase Surge Protection Device

PSP will, at its sole discretion, repair or replace any Three-Phase Vortexx Series R Surge Protection Device (SPD) that is defective or is damaged by a transient electrical spike (including those caused by lightning) for a period of twenty-five (25) years from the date of installation by the original owner

Exclusions

The above coverage applies to the original end user purchaser only and is the exclusive remedy under this warranty, whether based in contract, tort, including negligence, or otherwise. Claims must be made within 30 days of damage. This warranty does not cover damage associated with sustained over voltages, vandalism, theft, normal wear and tear, obsolescence, abuse, unauthorized modification or alteration, misuse, improper installation or catastrophic events.

PSP Products disclaims liability for any incidental, indirect, special or consequential damages arising out of the sale or use of any PSP products (including without limitation lost business profits, loss of data and all freight, mileage, travel time and insurance charges associated with warranty coverage claims).

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusions may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary from state to state. *This warranty is valid in the United States and Canada only.*

Claim Procedure

- 1. Contact PSP Products at 1-703-687-4057 to obtain a Return Authorization (RA) number
- 2. Return PSP device to PSP Products, freight prepaid.
- 3. PSP Products returns working device, freight prepaid.

Caution: Effective surge suppression requires correct wiring. All surge protection devices must be properly grounded for the warranty to be honored.



Warranty Assistance Call 703-687-4057 PSP Products Inc. 8618 Phoenix Drive, Manassas VA 20110 Register Online at: https://surgewarrantyonline.com