





### **TIMERS**

#### **Utility Return Transfer Timer**

Pins 3 & 4 & 5 Open = 129 Seconds Pins 3 & 4 shorted = 30 Seconds Pins 4 & 5 Shorted + 600 Seconds

#### **Utility Loss Timer**

Pins 6 & 7 Open = 5 Seconds Pins 6 & 7 shorted = 30 Seconds

#### **Generator Cool Down Timer**

Pins 8 & 9 & 10 Open = 10 Seconds Pins 8 & 9 shorted = 300 Seconds Pins 9 & 10 Shorted + 600 Seconds

Use shorting pins provided if changes are required


### **Preset Timers**

The KGC-1 is factory preset as follows: 5 second utility loss delay before starting the generator, 15 second delay before transferring after generator voltage is detected and a 2 minute delay before switching back to utility after power is restored. The generator ON contacts will open 10 seconds after the power transfers back to utility.

Optional weekly exercise timer available - Consult factory




# Generac® RTS Transfer Switch (up to 200A) to 2-Wire Start Installation






## Generac® RTS Transfer Switch (300A +) to 2-Wire Start Installation

## **OPTIONAL DIGITAL TIMER (DTS-1) AVAILABLE**








## Generac® RXS to 2-Wire Start Installation

## **OPTIONAL DIGITAL TIMER (DTS-1) AVAILABLE**





# Generac® GenReady Panel to 2-Wire Start Installation

